Series 16 Modules Controls – Solid State Plug-In Modules

- Compact Size
- ► Modular Plug-in Design
- ▶ Various Time Delays
- Low Voltage Sensor
- ▶ Solid State Reliability
- ▶ LED Monitoring
- ▶ U.L. "Motor Control"

Series 16M – General Purpose Control • New Microprocessor Design

Designed for either differential or single-level service. U.L. "Motor Controller" listing, 8 pin socket with screw-type connections make the unit easy to install and service. Sensitivity of up to 1 million ohm/cm.

Series 16HM – High Sensitivity Control

Series 16HM is similar to Series 16M but provides higher sensitivity up to 5.5 million ohm/cm. Probe voltage is 12 VDC for applications with low conductive media.

Series 16DM - DPDT Load Contact

Similar to Series 16M but with DPDT load contacts. Eliminates the need for slave relays. 11 pin octal plugs. Requires little panel space. General purpose single-level or differential applications. U.L. listed.

Series 16VM - Field Selectable Sensitivity

Similar to Series 16M but with the added flexibility of field adjustable sensitivity, made possible through external setpoint resistors. Uses 11pin octal socket. U.L. listed.

Specifications

*	
Contact Design	
Series 16M & 16HM	1 N.O. & 1 N.C. (1 form C)
Series 16DM	2 N.O. & 2 N.C. (2 form C)
Series 16VM	1 N.O. & 1 N.C. (1 form C)
Contact Rating (120. 240 VAC)	
Series 16M & 16HM	10 amp Resistive 1/3 hp
Series 16DM	5 amp Resistive 1/10 hp
Series 16VM	10 amp Resistive 1/3 hp
Mode of Operation	Direct/Inverse, factory set
Sensitivity	
Series 16M	0-1M ohm, factory set
Series 16HM	0-5.5M ohm, factory set
Series 16DM	0-1M ohm, factory set
Series 16VM	0-1M ohm, field adjustable
Primary Voltage	24 VAC, 120 VAC, 240 VAC (+10%/-15%)
	208/240: 187 V min. to 255 V max. VAC 50/60 Hz
Secondary Voltage	
Series 16M	12 VAC, 1.5 mA
Series 16HM	12 VDC
Series 16DM & 16VM	12 VAC, 1.5 mA
Temperature	-40°F to +150°F (-40°C to +65°C)
Approvals	U.L. 508 File #E44426
Terminal Style	Screw connector
Options	Time Delays
-	-






Series 16DM/16VM

Applications


- Single-Level Service
- · Point Level
- · Valve Control
- Differential Service
- Alarms
- Pump Control

Dimensions

Series 16M & 16HM



Series 16DM & 16VM




Note: Controls also available with DIN mount socket.




Wiring

Series 16M & 16HM




Note: For single level service, use "H" and "G" connections.


Series 16DM



Series 16VM



Variable Sensitivity Option




Part number 16Z1VG Potentiometer Board available for 16VM only. Consult factory.

How to Order


Use the **Bold** characters from the chart below to construct a product code.

16M Series – Microprocessor Version



8. Time Out Option See page E-11, Chart A

16 HM, 16DM or 16VM Series



Notes:

- 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select modes A, K, Y or Z only.
 1. 16VM select mode Specify a sensitivity to determine mode of operation.
- 16VM only.
- All Series except 16HM.
- 16VM only.
- Socket style M requires enclosure 0 None.
- 7. Mounting style A (11 pin octal only)

Socket Details and Option Availability are located on web site.

^{*}See page E-11 for descriptions.